

# FORKLIFT BATTERY MAINTENANCE



## ATTENTION OPERATOR

Your traction battery is an essential part of your forklift truck. Correct maintenance is important and you can play your part.

Batteries electrolyte levels should be checked WEEKLY & topped up if necessary

Top up batteries AFTER charge

Do not overfill each cell and avoid spillage

Top up to plastic indicator in bottom of each cell

Water/Electrolyte spilled into battery case stays in the bottom of the case and emits gases that cause many problems to the forklift.

If spillage occurs dry off excess water/electrolyte immediately

Remove all metal jewellery to avoid shorts

Never place metal objects across battery connectors

PPE for weekly check – Face Mask or Goggles, Nitrile Gloves, Rubber Apron.

Observe all operating & maintenance instructions supplied by the battery manufacturer.



If you require further information please contact Henley Forklift Group Ltd.  
Technical Support at 01-6209200  
or email [techsupport@henley.ie](mailto:techsupport@henley.ie)